


## Gel Ink Roller Ballpoint Pen / Use and Care Guide

Please refer to the proper Use and Care Guide before use.


### How to use

- (1) Before use, remove the cap and put it on the back side of the barrel.
- (2) After use, replace the cap.



### Replacement of the empty refill

- (1) Remove the cap.
- (2) Unscrew the neck from the barrel.
- (3) Pull out the empty refill.
- (4) Insert a new refill.
- (5) Retighten the barrel and the neck firmly.



- Refill for the gel ink ballpoint pen
- To verify compatible refills, scan the code below or visit the URL provided.
- Bring the refills you have been using to the store when purchasing a new one.



<https://www.pilot-refill.jp/en/gel>

### Remarks

- Do not use except for writing.
- Keep away from children.
- To prevent ink leakage, never write with the pen point upwards.
- Avoid severe impacts by violent shaking because the ink may leak.
- Always retract the writing tip after use. Always replace the cap firmly after use.
- Note that it may not be possible to remove this ink if it accidentally gets on your clothes.
- Do not store in places exposed to direct sunlight or high temperatures.