

Dr. GRIP 4+1

4 Colors Oil-based Ballpoint Pen + Mechanical Pencil
(BLACK / RED / BLUE / GREEN) (0.5mm)

4+1 LIGHT

4 Colors Oil-based Ballpoint Pen + Mechanical Pencil
(BLACK / RED / BLUE / GREEN) (0.5mm)

Acroball 4+1 / Use and Care Guide

4 Colors Oil-based Ballpoint Pen + Mechanical Pencil
(BLACK / RED / BLUE / GREEN) (0.5mm)

How to use


<Mechanical pencil>

- (1) Slide the clip and the writing unit for the mechanical pencil comes out and is set in place. [Fig.1]
- (2) Further press the top of the clip to extend the lead. [Fig.2]
- (3) To retract the lead, press it back into the writing unit while holding the top of the clip completely down.
- (4) To retract the tip, lightly slide another lever.
- (5) Take the cap off to use the eraser.

* For spare eraser, please use the PILOT **HERFNS-10**.


<Ballpoint Pen>

- (1) Slide the lever of the color you wish to use, and the tip comes out and is set in place.
- (2) To retract the tip, lightly slide another lever.



How to refill a mechanical pencil with new lead refills

- (1) While holding the grip, unscrew and remove the barrel.
 - (2) Hold the pen upwards and pull out the mechanical pencil writing unit. [Fig.3]
 - (3) Insert lead refills. [Fig.4]
(No more than three replacement refills should be inserted to avoid jamming.)
 - (4) Firmly insert the mechanical pencil's writing unit all the way in.
 - (5) Reassemble the pen by firmly screwing the barrels together.
- * Please use only genuine PILOT products (0.5 mm) for the mechanical pencil's lead refills.



How to replace the ballpoint pen refills

- (1) While holding the grip, unscrew and remove the barrel.
 - (2) Pull the empty refill out.
 - (3) Firmly insert a new replacement refill all the way in.
 - (4) Reassemble the pen by firmly screwing the barrels together.
- * The compatible refill for the Dr. GRIP 4+1 and Acro Ball 4+1 is the PILOT **BVRF-8** (Acro Ink), while the compatible refill for the 4+1 Light is the PILOT **BKRF-6F**.

Remarks

- Please do not use this product for any purpose other than writing.
- Handle with care because the point is sharp.
- Do not swallow the parts, such as the cap, eraser, and tip.
- Keep away from children.
- To prevent ink leakage, never write with the pen tip upwards.
- Avoid severe impacts or violent shaking because the ink may leak.
- Always retract the writing tip after use.
- Note that it may not be possible to remove this ink if it accidentally gets on your clothes.
- Do not store in places exposed to direct sunlight or high temperatures.